

REMOVING

Check for coded devices in the vehicle or devices that require continuous supply of energy.

- In case they exist in the vehicle, it is the authorized personnel who shall carry out the demounting.
- All consumers shall be turned off and the contact key shall be removed.
- When removing clamps be careful not to cause short circuit.
- Remove the marked cable (clamp) from the- terminal post by loosening clamp nut first, then repeat the procedure with + terminal post.
- Loosen the nuts on battery carrier and remove the battery carefully.